



living connect® living eco®

M28 ADAPTER (Herz) 014G0256



2 "702420"120430







(SYPTER (Herz)

013R9551 / VIHMJ302


How to remove a pre-mounted adapter




Remove the battery cover.



Insert a small hex key or similar into the locking hole.



With the hex key locking the adapter ring, turn the adapter in the shown direction.



Put back the battery cover and mount the *living* thermostat.